

Pk2 Solar Dancing Flame Lanterns

H502 v001: 19/04/21

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife

Always position in direct sunlight.



Dimensions

15.5 x 15.5 x13cm

- REALISTIC FLICKERING FLAME EFFECT
- 36 LED'S IN EACH LANTERN IN A WARM AMBER COLOUR
- SOLAR POWERED
- AUTOMATICALLY ILLUMINATES AT NIGHT
- ADDS A WARM AND RELAXING GLOW TO YOUR GARDEN AT NIGHT
- THE LOOK OF A REAL FLAME
- USE ON A TABLETOP OR HANG USING THE INTEGRAL HANGER

LEDs not replaceable.

Battery: 1 x AA 1.2V 200Mah, Ni-MH, rechargeable

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Before using first time

Remove the protective film from the solar panel. Allow lamp to charge for at least 8 hours in full sunlight with the ON/OFF switch in the ON position. The ON/OFF switch is located under the solar panel. Once the batteries are fully charged, set the ON/OFF switch to ON. If the lamp does not turn on after dark refer to Maintenance section.

Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

Charging and Operation:

Set switch (located on the top of solar panel case) to "ON" position. Press the ON/OFF button to "ON" position. Charge the solar product by placing it under direct sunlight for at least 8 hours.

The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.

NOTE: In order to test the lights simply cover the solar panel with your hand and light should turn on automatically.

*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

Important

- Install the solar product in an area where it can get direct sunlight.
- Leave the switch to "ON" position.
- Select an outdoor location away from other light sources at night, such as street lights. It may cause the product not to turn on automatically at night.
- Duration of light depends on solar product's level of sunlight exposure, geographical locations, weather conditions and the hours of daylight.

Care and Maintenance Recommendations

1. Make sure the switch is set to "ON" position.
2. Keep the solar panel clean.
3. If solar product does not light up after it has been used for around 8-12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1pc "AA" 1.2V 200Mah, Ni-MH, Rechargeable – Same equivalent type as recommended must be used.
4. Clean solar panel with a soft sponge every couple of weeks.
5. Make sure all connectors are still tight and no water getting in.
6. During the winter if you can bring it inside and give a good clean ready for next year.

Battery replacement

Step 1: Unscrew the battery compartment cover by using a Phillips head screwdriver (not included).

Step 2: Remove the exhausted battery and install 1 pc new AA rechargeable battery according to the +/- polarity as beside image. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.

Step 3: Replace the battery compartment cover, screw it back into position and make sure it is properly sealed.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

