Kissing Fairy Solar Light

H580 v002: 10/09/21

Please read and retain these instructions for future reference

GAINSBOROUGH

Garden & Wildlife ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions (H) 19 x(W) 12.5 x(D) 19cm

Composition Polyresin, plastic, glass

Solar light 1x Ni-MH AAA 300mAh 1.2V 1 x Warm White LED Lights (not replaceable)


ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Find an ideal Place for the Solar Light.

The solar panel is on the back of the product. The glass is inside the glass ball.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically



CHARGING AND OPERATION:

- Set button which is located underneath the solar panel to "ON" position for charging and charge by placing it <u>under direct sunlight for at least 8</u> <u>hours</u>.
- 2. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.

NOTE: In order to verify that the button is correctly in the "ON " position, cover the solar panel with your hand and light should turn "ON" automatically.

IMPORTANT:

- 1. Install the solar light in an area where it can get direct sunlight.
- 2. Leave the button to "ON" position.

Calls cost 7 pence per minute plus your telephone company's network access charge The Enterprise Department Head Office: 11 Bridge Street Bishop's Stortford, CM23 2JU Tel: 0844 482 4400 Fax: 01279 756 595 www.coopersofstortford.co.uk H580

Please read and retain these instructions for future reference

3. Select an outdoor location away from other light sources at night, such as street lights. It may cause the product not to turn on automatically at night.

4. Duration of light depends on solar product's level of sunshine exposure, geographical locations, weather conditions and the hours of daylight.

MAINTENANCE AND TROUBLESHOOTING:

- 1. Make sure the switch is set to "ON" position.
- 2. Keep the solar panel clean.
- If solar product does not light up after it has been used for around 8 12 months, replace the rechargeable batteries as they may be weak or worn out. (Battery 1pc "AAA" 1.2v 300Mah, Ni-MH, Rechargeable– Same equivalent type as recommended must be used).

BATTERY REPLACEMENT:

Step1: The battery compartment is located underneath the solar panel. Remove battery compartment cover by using a small Phillips head screwdriver (not included).

Step2: Remove the exhausted battery and install 1pc new AAA rechargeable battery according to the polarity symbol indicated on the battery compartment. Open the compartment carefully and ensure that welding wires inside the battery terminals are not damaged.

Step3: Replace battery compartment cover, screw it back into position and make sure it is properly sealed.

Cleaning and Maintenance Recommendations

- 1. Clean solar panel with a soft sponge every couple of weeks.
- 2. Make sure all connectors are still tight and no water getting in.
- 3. During the winter if you can bring it inside and give a good clean ready for next year.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



• Plastics, polybags – Contains the following recyclable plastic.

Calls cost 7 pence per minute plus your telephone company's network access charge The Enterprise Department Head Office: 11 Bridge Street Bishop's Stortford, CM23 2JU Tel: 0844 482 4400 Fax: 01279 756 595 www.coopersofstortford.co.uk H580

Please read and retain these instructions for future reference

Code & Symbol	€ PS	OTHER
Type of Plastic	Polystyrene	Please Specify (includes ABS, Nylon)
Commonly used for	Insulation boxes, water cups, protective packaging inserts, take away containers	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not commonly recycled but waste management centres will recycle it.	Not often or widely recycled

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



Calls cost 7 pence per minute plus your telephone company's network access charge The Enterprise Department Head Office: 11 Bridge Street Bishop's Stortford, CM23 2JU Tel: 0844 482 4400 Fax: 01279 756 595 www.coopersofstortford.co.uk