

## 200 LED WARM WHITE/MULTICOLOURED

H582 WW/MC v001: 26/03/21

Please read and retain these instructions for future reference

# GAINSBOROUGH

Garden & Wildlife

ALWAYS POSITION IN DIRECT SUNLIGHT



Total length: 21.9m

Battery 1 pc AA 1.2v 800Mah, Ni-MH,  
Rechargeable (included)

H582 WW 200 LED Warm White  
H582 MC 200 LED Multicolour

### ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

This product consists of a solar cell, rechargeable battery and LED light. During the day, sunlight charges the battery. At night, the energy stored in the battery is used to power the light. No other power or connections are required. The length of time the light will stay on for depends on how much sunlight has been received during the day.

The solar panel should be located where sunlight can fall directly on it – avoid shadows from buildings, trees, walls, hedges and similar objects, as these will reduce performance.

**Please read and follow all instructions before operating your lights. Save this manual for future reference.**

**BEFORE FIRST USE: Remove the protective film from the solar panel.**

### CHARGING AND OPERATION:

1. Set switch (located on the back of solar case) to “ON” position. Charge the solar product by placing it under direct sunlight for at least 8 hours.
2. The light will work automatically. It will automatically charge under direct sunlight during the day time and illuminate at night.
3. This solar lights has “Flashing” function as well. Turn switch to “ON” position and press “MODE” button you can achieve the “FLASHING” function.

NOTE: In order to verify that the switch is correctly in the “ON” position, cover the solar panel with your hand and the light should turn on automatically.

### IMPORTANT:

1. Install the solar product in an area where it can get direct sunlight.
2. Leave the switch to “ON” position.

\*Calls cost 7 pence per minute plus your  
telephone company's network access charge

The Enterprise Department  
Head Office: 11 Bridge Street  
Bishop's Stortford, CM23 2JU  
Tel: 0844 482 4400\*  
Fax: 01279 756 595  
www.coopersofstortford.co.uk

# 200 LED WARM WHITE/MULTICOLOURED H582 WW/MC Instructions for Use

Please read and retain these instructions for future reference

v001: 26/03/21

3. Select an outdoor location away from other light sources at night, such as street lights. It may cause the product not to turn on automatically at night.
4. Duration of light depends on solar product's level of sunlight exposure, geographical locations, weather conditions and the hours of daylight.

## MAINTENANCE

- Clean with a soft damp cloth.
- Do NOT use abrasives or solvents.
- Do NOT disassemble or attempt to repair the solar marker housing other than to replace the rechargeable battery.
- Clean regularly as a build up of dirt on the solar panel will reduce performance.
- Make sure the switch is set to "ON" position.
- Keep the solar panel clean.
- If solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable batteries as they may be weak or worn out. (Battery 1 pc "AA" 1.2v 600Mah, Ni-MH, Rechargeable– Same equivalent type as recommended must be used).

## Battery replacement:

Step1: Unscrew the battery compartment cover by using a Phillips head screwdriver (not included) .

Step2: Remove the exhausted battery and install 1 pc new AA rechargeable battery according to the +/- polarity as beside image. Open the compartment carefully and ensure that welding wires inside the battery terminals are not damaged.

Step3: Replace battery compartment cover, screw it back into position and make sure is properly sealed.


## BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

## DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	ABS

\*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department  
Head Office: 11 Bridge Street  
Bishop's Stortford, CM23 2JU  
Tel: 0844 482 4400\*  
Fax: 01279 756 595  
[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

# 200 LED WARM WHITE/MULTICOLOURED H582 WW/MC Instructions for Use

Please read and retain these instructions for future reference

v001: 26/03/21

Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



\*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department  
Head Office: 11 Bridge Street  
Bishop's Stortford, CM23 2JU  
Tel: 0844 482 4400\*  
Fax: 01279 756 595  
[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)