

# Set 2 Solar Squirrel Stakes

H740 v001: 21/06/21

Please read and retain these instructions for future reference

**GAINSBOROUGH**  
Garden & Wildlife

**ALWAYS POSITION IN DIRECT SUNLIGHT**



## Dimensions

(H) 43 x (W) 10 x (D) 8cm

- CUTE & CHARMING HAPPY SQUIRRELS WITH THEIR ACORN TREATS
- AT NIGHT TIME THE ACORNS AUTOMATICALLY ILLUMINATE TO GIVE A WARM AUTUMN GLOW
- SOME FESTIVE CHEER FOR YOUR GARDEN FOR WHEN THE SEASON CHANGES
- SOLAR POWERED
- ADD TO PLANT POTS OR BEDS
- MADE OF WEATHERPROOF POLYRESIN AND PLASTIC

1x 1.2V AAA 300 MAH per light required (included)

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

### Before using first time

#### Step 1:

Fully charge the battery before first use. Charge under direct sunlight in the <ON> position for 2 days.

#### Step 2:

Your solar light will automatically turn on once it gets dark.

### Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically.

## IMPORTANT

- Fully charge the battery before first use.
- For best results, locate your solar lamp in a position where it can get direct sunlight on the solar panel and generally free from cover and shade.
- Keep your solar lights away from other night-time light sources, such as streetlights.
- Make sure the solar panels are not covered by dust, snow and debris. Clean it with a soft damp cloth or paper towel periodically. Avoid the use of abrasive cleaning agents.
- Use only rechargeable batteries for your solar lights. Replace with a new battery of the same size each year for optimum performance.

\*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department  
Head Office: 11 Bridge Street  
Bishop's Stortford, CM23 2JU  
Tel: 0844 482 4400\*  
Fax: 01279 756 595  
www.coopersofstortford.co.uk

## CHANGING THE BATTERY

### Step 1:

Push the switch to the <OFF> position.

### Step 2:

Remove the screws from the battery cover.

### Step 3:

Carefully lift the cover to access the battery compartment, being sure not to detach any of the connected wires

### Step 4:

Replace the battery with an equivalent new solar rechargeable battery; ensuring the correct polarity is observed

### Step 5:

Reassemble the unit by reversing the above procedure.



## TROUBLE SHOOTING TIPS

If your solar light does not come on at dusk despite following all instructions please try the following steps:

1. Make sure that the solar light is not affected by any other light source.
2. Ensure the solar light does not stand in the shade all day.
3. Check to see if the batteries are installed correctly.
4. If there is a protective film on the solar panel remove it.

## Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.
3. During the winter if you can bring it inside and give a good clean ready for next year.



## BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

## DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 PS	 OTHER
Type of Plastic	Polystyrene	ABS
Commonly used for	Insulation boxes, water cups, protective packaging inserts, take away containers	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not commonly recycled but waste management centres will recycle it.	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

