

20pc Mushroom Solar Stake Lights

K204 v001: 06/10/21

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife

ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions

EACH MUSHROOM IS 20CM HIGH INC GROUND STAKE

TOTAL Length: 5.8m

LIGHT STRING: 380cm

2M CABLE FROM SOLAR PANEL TO THE FIRST MUSHROOM IN THE LIGHT STRING

Material: Plastic

Batteries required: 1.2V AA 300mAH Ni-MH rechargeable (included)

LED bulbs not replaceable

- THERE ARE 20 SOLAR MUSHROOMS IN TOTAL EACH WITH A STAKE TO FIX THEM INTO THE GROUND
- EACH MUSHROOM IS 20CM APART FROM EACH OTHER
- AUTOMATICALLY ILLUMINATES AT DUSK
- LIGHTS SETTINGS OF ON/ OFF/ FLASHING

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Before using first time

Allow solar panel to charge for at least 8 hours in full sunlight with the ON/OFF switch in the ON position. The ON/OFF switch is located under the solar panel. Once the batteries are fully charged, set the ON/OFF switch to ON. If the lights do not turn on after dark refer to Maintenance section.

Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

Caution: Locate where the lights will not create a trip hazard.

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first

*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

then gently insert the rest of the stake into the base. DO NOT push directly against the solar cell or the ornament housing containing the actual LED light.

Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.

Troubleshooting


If the solar light does not turn on automatically at night, please check the following:

- Is the switch in the on position?
- Battery is not fully charged:
Ensure the solar panel is positioned where it will receive plenty of direct sunlight. This item should not be placed in shady areas or the battery will not charge and the light will not function properly.
- Battery needs replacement:
Replace the battery when the lights are no longer functional or are very dim during summer months.
- Loose battery:
Sometimes the battery may become dislodged from the terminals and no contact is made. Make sure the battery is firmly in contact with the terminal at each end of the battery holder.
- Dirty Solar panel:
A dirty solar panel will not allow the battery to fully charge. Clean the solar panel with a damp sponge, cloth or paper towel.
- Light does not turn on:
The light is designed to switch on when it turns dark, if there are strong light sources nearby then the lights may be dim or not turn on.

Replacing Battery

The life of the rechargeable battery is approximately 6-12 months. When the light becomes dim or is no longer functional, it may be time to change the battery.

- Push the switch to the off position. Using a Phillips head screwdriver (not included), remove the screws on the underside of the panel.
- Take out the battery replacing with a new 1x AA 1.2V 300mAh Ni-MH rechargeable battery.
- Do not replace with a normal alkaline battery.
- Do not disconnect or remove any wires or tamper with any other connections inside or around the compartment.
- Replace the battery cover and screw back into place.



BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.

- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



- Plastics, polybags – this is made from the following recyclable plastic PP .
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

