1.5m Solar Willow Tree

K232 v001: 11/10/21

Please read and retain these instructions for future reference



ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions

(H) 150 x (W) 22 x (D) 22cm

Material

Silk and Plastic

Battery

1x AA 1.2v 600Mah, Ni-MH, Rechargeable (included)

- PRETTY WEEPING WILLOW TREE IS SCATTERED WITH WARM WHITE SOLAR LIGHTS
- THE CASCADING LEAVES WILL RUSTLE IN THE WIND
- POSITION BY A DOOR, IN A CORNER OF YOUR PATIO, FLOWER BED ETC AND ENJOY DAY AND NIGHT
- SEPARATE SOLAR PANEL SO YOU CAN POSITION IN OPTIMAL SUN LIGHT
- 120 WARM WHITE LEDS (NOT REPLACEABLE)
- 12 BRANCHES EACH AROUND 90CM LONG AND WITH 10 LEDS ON
- COMES WITH 4 GROUND PEGS TO FIX THE BASE INTO SOFT GROUND

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

BEFORE FIRST USE: Remove the protective film from the solar panel.

CHARGING AND OPERATION:

- 1. Set switch (located on the back of solar case) to "S (steady on)" OR "F (flash)" position. Charge the solar product by placing it under direct sunlight for at least 8 hours.
- 2. The light will work automatically. It will automatically charge under direct sunlight during the day time and illuminate at night.

NOTE: In order to verify that the switch is correctly in the "S" OR "F" position, cover the solar panel with your hand and the light should turn on automatically.

Find an ideal Place for the Solar Light.

Place the solar panel in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the panel is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the solar panel near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

Instructions for Use

Please read and retain these instructions for future reference

v001: 11/10/21

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base.

Battery replacement:

- Step1: Unscrew the battery compartment cover by using a Phillips head screwdriver (not included) .
- Step2: Remove the exhausted battery and install 1x new AA 1.2V 600Mah, Ni-MH rechargeable battery according to the +/- polarity as beside image. Open the compartment carefully and ensure that welding wires inside the battery terminals are not damaged.
- Step3: Replace battery compartment cover, screw it back into position and make sure is properly sealed.
- Step4: Charge battery for at least 8 hours in direct sunlight.



Care and Maintenance Recommendations

- 1. Clean solar panel with a soft sponge every couple of weeks.
- 2. Make sure all connectors are still tight and no water getting in.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags this is made from the following recyclable plastic.



Instructions for Use

v001: 11/10/21

Code & Symbol	£	2	4
	PETE	HDPE	LDPE
Type of Plastic	Polyethylene Terephthalate	High-Density Polyethylene	Low Density Polyethylene
Commonly	Soft drink and juice bottles, shampoo bottles, meat	Milk bottles, cleaning product bottles, yoghurt pots, butter	Shopping bags, bread bags, squeezy bottles, stretch/pallet
used for	trays, fruit punnets	tubs and other food containers	wrap, bubble wrap, multi-pack can holders
	Commonly recycled and	Commonly recycled and	Usually recyclable supermarket
	collected from household	collected from household	deposit points. Check other
Notes	recyclign bins. Check with	recycling bins. Check with your	plastic films as any non-
	your local authority	local authority	polythene film e.g. cling film, crisp packets film lids

At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



