

# Reading Boy & Girl With Solar Light

K322 v001: 15/12/21

Please read and retain these instructions for future reference

**GAINSBOROUGH**  
Garden & Wildlife

**ALWAYS POSITION IN DIRECT SUNLIGHT**



## Dimensions

(H) 52 x (W) 25 x (D) 23cm

Material: Polyresin

- SOLAR POWERED LANTERN THAT AUTOMATICALLY ILLUMINATES AT NIGHT
- CRAFTED IN DETAIL OUT OF WEATHER PROOF POLYRESIN MADE TO LOOK LIKE NATURAL STONE
- SITTING AT AN IMPRESSIVE 52CM TALL IT MAKES A GREAT CENTRE PIECE FOR YOUR GARDEN

Battery: 1x AA NI-MH included)

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

### OPERATION

#### FOR FIRST TIME USE:

##### Step 1:

Fully charge the battery before first use. Charge under direct sunlight in the <ON> position for 2 days.

##### Step 2:

Your solar light will automatically turn on once it gets dark.

#### **Find an ideal Place for the Solar Light.**

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The solar panel is located on the top of the lantern. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

\*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department  
Head Office: 11 Bridge Street  
Bishop's Stortford, CM23 2JU  
Tel: 0844 482 4400\*  
Fax: 01279 756 595  
[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

# Reading Boy & Girl With Solar Light K322 Instructions for Use

Please read and retain these instructions for future reference

v001: 15/12/21

## CHANGING THE BATTERY

### Step 1:

Push the switch to the <OFF> position (Figure 1).

### Step 2:

Remove the screws from the battery cover (Figure 1).

### Step 3:

Carefully lift the cover to access the battery compartment, being sure not to detach any of the connected wires (Figure 2).

### Step 4:

Replace the battery (1x AA NI-MH) with an equivalent new solar rechargeable battery; ensuring the correct polarity is observed (Figure 2).

### Step 5:

Reassemble the unit by reversing the above procedure.

Figure 1



Figure 2



## TROUBLE SHOOTING TIPS

If your solar light does not come on at dusk despite following all instructions please try the following steps:

1. Make sure that the solar light is not affected by any other light source.
2. Ensure the solar light does not stand in the shade all day.
3. Check to see if the batteries are installed correctly.
4. If there is a protective film on the solar panel remove it.

## Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.

## BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

# Reading Boy & Girl With Solar Light K322 Instructions for Use



Please read and retain these instructions for future reference

v001: 15/12/21

## DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol		
Type of Plastic	Polypropylene	ABS
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

