

SOLAR WALL LIGHT FLOWER CUT OUT

PACK OF 2

K325 v001: 17/01/22

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife

ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions

(H) 27 x (W) 13 x (D) 7

- BRONZE EFFECT SOLAR LIGHTS WITH PRETTY FLOWER CUT OUT DESIGN
 - CONTRASTING LIGHT GOLD COLOUR INSIDE WHICH WHEN ILLUMINATED REALLY HIGHLIGHTS THE PRETTY FLOWER DESIGN
 - SOLAR POWERED WITH INTEGRAL SOLAR PANEL IN THE TOP OF EACH LIGHT SO NO TRAILING WIRES
 - IDEAL FOR FIXING TO FENCES, EITHER SIDE OF YOUR DOOR, SHED ETC FOR A WARM AND PRETTY EVENING GLOW
 - HANGING HOOK ON THE BACK (NO SCREWS/ FIXINGS INCLUDED)
- BATTERY: CONTAINS 1XAA NIMH

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Before using first time

Step 1:

Fully charge the battery before first use. Charge under direct sunlight in the <ON> position for 2 days.

Step 2:

Your solar light will automatically turn on once it gets dark.

NOTE: In order to verify that the button is correctly in the "ON" position, cover the solar panel with your hand and light should turn "ON" automatically.

Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

TROUBLE SHOOTING TIPS

If your solar light does not come on at dusk despite following all instructions please try the following steps:

1. Make sure that the solar light is not affected by any other light source.
2. Ensure the solar light does not stand in the shade all day.
3. Check to see if the batteries are installed correctly.

*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

SOLAR WALL LIGHT FLOWER CUT OUT PACK OF 2 K325 Instructions for Use

Please read and retain these instructions for future reference

v001: 17/01/22

4. If there is a protective film on the solar panel remove it.

Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.

CHANGING THE BATTERY

Step 1:

Push the switch to the <OFF> position (Figure 1).



Fig 1

Step 2:

Remove the screws from the battery cover (Figure 1).



Fig 2

Step 3:

Carefully lift the cover to access the battery compartment, being sure not to detach any of the connected wires (Figure 2).

Step 4:

Replace the battery with an equivalent new solar rechargeable battery (1*AA NI-MH); ensuring the correct polarity is observed (Figure 2).

Step 5:

Reassemble the unit by reversing the above procedure.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.





SOLAR WALL LIGHT FLOWER CUT OUT PACK OF 2 K325 Instructions for Use

Please read and retain these instructions for future reference

v001: 17/01/22

- Plastics, polybags – this is made from the following recyclable plastic.

| | | |
|-------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| Code & Symbol |  |  |
| Type of Plastic | Polystyrene | ABS |
| Commonly used for | Insulation boxes, water cups, protective packaging inserts, take away containers | CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses |
| Notes | Not commonly recycled but waste management centres will recycle it. | Not often or widely recycled |

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk