Solar Owl Lantern Stake

K747 v001: 06/05/22

Please read and retain these instructions for future reference



ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions

(H) 79.5 x (W) 15.8 x (D) 15.8cm

- INTEGRAL SOLAR PANEL
- AUTOMATICALLY TURNS ON AT DUSK
- 1 YELLOW LED LIGHT WITH FLICKER (not replaceable)
- LANTERN H27.6 X W14.1 X D14.1 CM
- DECORATIVE OWL DESIGN
- SOLAR POWERED
- TOP RING FOR EASY HANGING
- SUITABLE FOR HANGING OR FREE STANDING

Batteries required: 1 x AA 1.2v 200MaH Ni-MH Battery (included)

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

BEFORE FIRST USE: Remove the protective film from the solar panel.

Charging and operation:

- 1. There is an "on/off" switch at bottom of the lantern. Push the switch to the "on" position. Then position the light in a sunny location. Charge the solar product by placing it under direct sunlight for at least 8 hours.
- 2. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.



On/Off switch

NOTE: In order to test the lights simply cover the solar panel with your hand and the light should turn on automatically.

Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically



UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

Solar Owl Lantern Stake K747

Instructions for Use

Please read and retain these instructions for future reference

v001: 06/05/22

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base. DO NOT push directly against the solar cell or the ornament housing containing the actual LED light.

Battery replacement:

If the light stops working after it has been used for a long time (about 18 months), the battery may be beyond its lifespan. Please open the cover of the battery compartment

to replace the rechargeable battery.

Step1: Remove the battery compartment cover.

Step2: Remove the exhausted battery and install 1x new AA

rechargeable battery according to the +/-

polarity as image inside compartment. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.

Step3: Put battery compartment cover back properly and safely.

Step4: Charge battery for at least 8 hours in full sunlight.



Care and Maintenance Recommendations

- 1. Clean solar panel with a soft sponge every couple of weeks.
- 2. Make sure all connectors are still tight and no water getting in.

BATTERIES

- Keep batteries away from children and pets.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

Solar Owl Lantern Stake K747

Instructions for Use

Please read and retain these instructions for future reference

v001: 06/05/22

DISPOSAL

Coopers of Stortford use recyclable or recycled packaging where possible. Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	ês Ps
Type of Plastic	Polystyrene
Commonly used for	Insulation boxes, water cups,protective packaging inserts, take away containers
Notes	led but waste management centres will recycle it.

At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.council authorised household waste recycling centre for disposal.

