

# Wifi Booster

L441 v001: 09/09/22

Please read and retain these instructions for future reference

# BERGSTRÖM



## Dimensions

(H) 11 x (W) 5.7. x (D) 6cm

Material: ABS, PC

- OUR WIRELESS WI-FI REPEATER HELPS TO INCREASE THE REACH OF YOUR WI-FI SO YOU CAN USE IT NO MATTER WHERE YOU ARE IN THE HOUSE, IT CAN EVEN POTENTIALLY REACH TO YOUR GARDEN, SO YOU CAN ENJOY YOUR ENTERTAINMENT FROM THE RELAXATION OF YOUR GARDEN CHAIR!
- FREQUENCY – 2.4GHZ TO 2.4835GHZ
- POWER REQUIREMENTS – 110V – 230V SOCKET
- COMPATIBLE WITH 802.11N/G/B DEVICES
- STABLE SIGNAL AND HIGH TRANSMISSION SPEED





## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

- includes 1 x WIFI wireless repeater, 1XRJ45 network cable

## INSTRUCTIONS FOR USE

### LED Explanation

Icon	Indication	Status
	POWER LED	<b>NO:</b> The device is power on <b>OFF:</b> The Device is not receiving electrical power
	WLAN LED	<b>Wireless signal</b>
	WPS LED	<b>Flashing:</b> WPS connection is established or WPS signal of another device is expected
	LAN LED	<b>NO:</b> The LAN port is connect <b>OFF:</b> The LAN port is disconnected <b>Flashing:</b> Transferring data to/from a network device

# The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.







6



7



## The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)


EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.

8


u k y k V  
k k ; ) tk, ut k k  
@ k k



9


## B. Configure the Wireless AP Mode.

1. Plug the Wi-fi Repeater into a wall socket
2. Follow process A3 to A5
3. Click on 'AP Mode' to continue.



10

4. The following message will be displayed on your web browser.



Click on ' Save ' button, The Repeater will restart,  
Wait a few seconds your Wi-Fi Repeater is ready for use.

## Relocate

Plug in the Wi-fi booster halfway between your router and the Wi-Fi dead zone.




The repeater Wi-fi booster to the end of the host network's SSID and uses the same Wi-Fi password.

### DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	ABS, PC
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

