

# Bergstrom 12L Dehumidifier


Item No: P722

## Instructions for Use

v002: 08/05/2025

Please read and retain these instructions for future reference

# BERGSTRÖM




**Power Details:** Voltage details: AC 220-240V~  
Frequency details: 50Hz  
Wattage details: 300W

**Accessories:** Continuous drainage hose  
Castors (can be attached to the base of the unit if moved frequently)

**Use:** This item should be moved using two hands to ensure safe use.

**Please read this instruction manual thoroughly before use to ensure you are familiar with the operation, and use of your new Bergstrom 12L Dehumidifier.**

### Part Names & Functions



Risk of Fire



Caution! This dehumidifier has a compressor and refrigerant inside, which is flammable and may explode if heated.

Keep away from sources of heat and fire.


Keep away from children.

Do not dispose in fires.


Dispose safely at your local authority waste site.

## Installation

The following clearances around the unit must be ensured for safety, and to ensure the correct operating efficiency of the dehumidifier.



## Operation Panel



## Operating Instructions

- **Switch**

Used to turn the humidifier on and off.

- **Mode**

The dehumidifier has four different operating modes, which can be selected using this button. The modes are as follows:

- Normal Mode
  - The Normal Mode ensures the dehumidifier will operate within its operating range until switched off.

- Continuous Mode
    - In this mode the unit can be set to achieve a desired humidity level (see section below for instructions).
  - Drying (Laundry) Mode
    - This mode ensures the unit operates at maximum speed to assist in the drying of laundry. For best results, operate in a closed room, but do not keep the unit too close to the laundry, to ensure good air flow (which speeds up drying).
  - Ventillation (Fan only) Mode
    - In this mode, the unit will only blow air, and will not attempt to dehumidify.
- **'+' & '-' Buttons**

These buttons can be used to set the desired humidity level. This is only effective when the unit is operating in continuous mode. The unit can be set between 30% and 80% humidity. Once the desired humidity level has been selected the unit flash the humidity level, and stop flashing after 5 seconds. The dehumidifier will operate to achieve the selected humidity level, stopping and starting as required.

- **Timer Function**

Pressing the timer function will change the display to show hours. The unit can be set to operate between 0 and 24 hours. Pressing the timer button will adjust by an hour with each press. The display will flash for 5 seconds after the desired time has been set, and exit the setting function.

- **Wind (Fan) Speed**

This function can be used when in ventilation mode only, and allows the selection of high or low fan speeds.

- **Child Lock Function**

Pressing both the Timer and Wind Speed buttons simultaneously for 3 seconds makes the unit enter child lock mode. This stops the accidental pressing / changing of settings. To remove the unit from the mode, follow the same operation again.

- **Full of Water**

This light will illuminate if the water tank is full. The unit will not operate with a full tank. The capacity of the water tank is approximately 2L.

- **Defrost**






The evaporator in the dehumidifier may defrost automatically if it is operated in a room with a temperature less than 18 C. Should this occur, the defrost light will illuminate. This process may occur intermittently for up to 5 minutes, and is a correct process to ensure the unit is not damaged.

During the defrosting operation, the dehumidification function will be intermittent. Please don't turn off the dehumidifier or pull out the power plug of the dehumidifier during this process, to ensure no damage to the unit.


***Please Note:***

This dehumidifier does not have a cooling function, and so will produce heat during normal operation. In an enclosed environment, this can result in noticeable warming. This is entirely normal.

## Preparations before Operation

<p><b>To Remove the Water Tank</b></p> <p>Hold the sides of the tank, and gently pull out.</p>	
<p><b>Emptying the Water Tank</b></p> <p>Gently tip the tank (noting the indicated direction), and slowly empty the water</p>	
<p><b>Replacing the Water Tank</b></p> <p>Align the tank back with the dehumidifier, and push firmly (but gently) back into the unit.</p>	
<p><b>Cleaning the Filter</b></p> <p>We advise the filter is cleaned and rinsed every two to three weeks. Once rinsed, the filter should be allowed to dry before being replaced.</p> <p>Ensuring the unit is clean of dust / debris will ensure the dehumidifier will function better.</p>	
<p><b>Continuous Drainage</b></p> <p>The unit can be operated on continuous mode by installing the drainage hose (included).</p> <p>Remove the bung from the plug and attach the hose.</p> <p>Ensure the other end of the hose is inserted into an appropriate drain, so as not to flood (auto turn off will not operate in this mode)</p>	

## Dehumidifying Capacity



The illustration above shows the maximum daily dehumidifying capacity of this dehumidifier. Its stated 12L / day dehumidification is when operating in a room with 80% relative humidity, and 30 C. Useage at a lower temperature, and humidity level will result in the extraction of a lower quantity of water, and does not mean the unit is not operating correctly.

This capacity data is when the air outlet is fully open. At different temperatures and relative humidity, the unit will operate at differing dehumidification rates.

In the same room temperature, the dehumidifying capacity is higher in higher relative humidity and the dehumidifying capacity is lower in lower relative humidity.

### Troubleshooting

Issue	Possible Cause
Intermittently stopping during operation	The unit may be in defrosting mode (see defrost section above)
Lower dehumidifying rate than expected	The dehumidifying capacity drops depending on the room temperature and humidity. See the relevant section above for reference.
The humidity of the room doesn't reduce	The room area may be too large, which is over the recommended room size for this unit (20 – 30m2)  The door and windows of the room aren't closed.
Unpleasant smell	The filter may need to be cleaned
The dehumidifier unit makes noise during operation.	The noise may be caused by the flow of refrigerant within the unit. This is normally caused when the unit is extracting larger quantities of water.
The FULL indicator light is on.	When the water tank is full, the FULL indicator light is on to remind you to empty the tank (see relevant section above).

### Warnings & Safety Instructions



Risk of Fire

Caution! This dehumidifier has a compressor and refrigerant inside, which is flammable and may explode if heated.

Keep away from sources of heat and fire.

Keep away from children.

Do not dispose in fires.

Dispose safely at your local authority waste site.

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED:

- READ ALL INSTRUCTIONS BEFORE USE.
- FOR DOMESTIC INDOOR USE ONLY.
- BEFORE USE, CHECK THOROUGHLY FOR ANY DEFECTS AND DO NOT USE IF DEFECTS ARE FOUND. TAKE CARE NOT TO DROP THE APPLIANCE AS HEAVY IMPACTS MAY CAUSE INTERNAL DAMAGE.
- BEFORE CONNECTING THE APPLIANCE, CHECK IF THE VOLTAGE INDICATED ON THE BOTTOM OF THE APPLIANCE IS IN ACCORDANCE WITH THE MAINS VOLTAGE IN YOUR HOME.
- CHECK THE APPLIANCE AND POWER CABLE CAREFULLY FOR DAMAGE BEFORE EACH USE.
- THIS APPLIANCE CAN BE USED BY CHILDREN AGED FROM 8 YEARS AND ABOVE, AND PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES OR LACK OF EXPERIENCE AND KNOWLEDGE IF THEY HAVE BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE APPLIANCE IN

A SAFE WAY AND UNDERSTAND THE HAZARDS INVOLVED. CHILDREN SHALL NOT PLAY WITH THE APPLIANCE. CLEANING AND USER MAINTENANCE SHALL NOT BE MADE BY CHILDREN WITHOUT SUPERVISION.

- CHILDREN OF LESS THAN 3 YEARS SHOULD BE KEPT AWAY UNLESS CONTINUOUSLY SUPERVISED.
- **SOME PARTS OF THIS PRODUCT CAN BECOME VERY HOT/COLD AND CAUSE BURNS. PARTICULAR ATTENTION HAS TO BE GIVEN WHERE CHILDREN AND VULNERABLE PEOPLE ARE PRESENT.**
- THE USE OF ANY ACCESSORY OR ATTACHMENTS NOT RECOMMENDED BY COOPERS OF STORTFORD MAY CAUSE INJURIES AND INVALIDATE ANY WARRANTY YOU MAY HAVE.
- DO NOT LET THE POWER CABLE HANG OVER THE EDGE OF A TABLE OR COUNTER, OR TOUCH HOT SURFACES.
- DO NOT PLACE ON OR NEAR HEAT SOURCES.
- USE ON A LEVEL, STABLE SURFACE.
- DO NOT COVER THE ITEM IN ANY WAY WHEN IN USE AS THIS MAY CAUSE OVERHEATING.
- DO NOT USE THIS APPLIANCE FOR ANY OTHER USE THAN THE INTENDED USE IT IS DESIGNED FOR.
- ENSURE THERE IS SUFFICIENT DISTANCE BETWEEN THIS APPLIANCE AND OTHER ITEMS ON THE WORK SURFACE OR WORK STATION, OR SUFFICIENT DISTANCE BETWEEN THE APPLIANCE AND THE CONFINES OF THE AREA IN WHICH IT IS SITUATED. WE RECOMMEND A MINIMUM CLEARANCE AROUND ALL FACES OF AT LEAST 10CM.
- TO PROTECT AGAINST ELECTRIC SHOCK, DO NOT IMMERSE POWER CABLE, PLUG OR APPLIANCE, IN WATER OR ANY OTHER LIQUID.
- UNPLUG FROM OUTLET WHEN NOT IN USE AND BEFORE CLEANING.
- DO NOT OPERATE ANY APPLIANCE WITH A DAMAGED POWER CABLE OR PLUG OR AFTER THE APPLIANCE MALFUNCTIONS, OR HAS BEEN DAMAGED IN ANY MANNER. WE RECOMMEND THAT THE POWER CABLE IS NOT KINKED OR STORED IN A TWISTED MANNER, AND THAT YOU REGULARLY CHECK ITS CONDITION.
- DO NOT LEAVE UNATTENDED.
- ALLOW TO COOL BEFORE CARRYING OR PLACING IN STORAGE.
- ANY REPAIRS MUST BE CONDUCTED BY A QUALIFIED ELECTRICIAN OR ELECTRICAL SERVICE AGENT.

#### Plug Wiring (UK & Ireland)

This appliance is fitted with a moulded BS 1363 13-amp plug. This is fitted with a 13 amp fuse.

If you have to replace the fuse, only those that are ASTA or BSI approved to BS1362 should be used.


If there is a fuse cover fitted, this cover must be re-fitted after changing the fuse. If the fuse cover is lost or damaged the plug must not be used. Spare fuse holders and fuses are available from electrical outlets. If the socket outlets in your home or office are not suitable for this product's plug, the plug must be removed and disposed of safely. Attempts to insert the plug into the wrong socket are likely to cause an electric hazard.








#### Care & Cleaning Instructions

- Always switch off and unplug before cleaning.
- Do NOT immerse in water. Risk of electric shock.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Wipe surfaces with a soft dry cloth.
- Allow to dry thoroughly before further use.
- Store the appliance in a cool, dry place.

## Disposal

- We use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons in accordance with your local authority recycling regulations.
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.
- Plastics, polybags – this is made from the following recyclable plastic.




Code & Symbol	 PETE	 HDPE	 PVC	 LDPE	 PP	 PS	 OTHER
Type of Plastic	Polyethylene Terephthalate	High-Density Polyethylene	Polyvinyl Chloride	Low Density Polyethylene	Polypropylene	Polystyrene	Please Specify (includes ABS, Nylon)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

Distributed by / Verteilt durch / Distribué par. / Distribútor / Distribuuje

The Enterprise Department Ltd, Trading as Coopers of Stortford.  
**UK address:** 11 Bridge Street, Bishops Stortford  
Herts, UK, CM23 2JU




 0330 331 0300

 [enquiries@coopersofstortford.co.uk](mailto:enquiries@coopersofstortford.co.uk)

 <https://www.coopersofstortford.co.uk>

The Enterprise Department Ltd, Trading as:  
**NI address:** D.S.B. LD, 160 Bd. De Fourmies, 59100 Roubaix, France

 +44 (0)330 331 0300


 [enquiries@coopersofstortford.co.uk](mailto:enquiries@coopersofstortford.co.uk)

 <https://www.coopersofstortford.co.uk>

DE/FR/CZ/SK :

**3Pagen**

Hergestellt für 3Pagen  
Sankt-Joeris-Strasse 16-28  
53477 Alsdorf

 +49 (0) 2404/980-204

 [kontakt@3pagen.de](mailto:kontakt@3pagen.de)

 <https://www.3pagen.de>