

BEFORE YOU START


Altering or modifying the lamp in any way will render the product unsafe.

- Inspect the lamp before assembly. Some wire connections have been made at the factory and the lamp is ready for assembly.
- Remove all packing materials from the lamp.
- To prevent bad connections, avoid pulling wiring connections when removing contents from package or during installation.
- Lay out all the parts on a flat surface.

ASSEMBLY

NOTE: TAKE CARE NOT TO SCRATCH THE POWER CORD DURING ALL ASSEMBLY STEPS.

1. Place lamp base (A) on a stable, flat surface.
2. Remove the black rubber protector (B) around the wires on the base (A) (this is to protect the wires in transit).
3. Screw the cylinder (C) onto the base (A). Then, remove the preassembled screw (D) from the cylinder (C).
4. Push the power cord from lamp head through the upper tube (G) and the lower tube (F).
5. Screw the upper tube (G) clockwise to the gooseneck (H).
6. Screw the lower tube (F) clockwise to the upper tube (G).
7. Connect the two ends of the power cord by pressing the wire connectors (E) into place.
8. Carefully tuck the excess power cord into the lower tube (F).
9. Align the hole on the lower tube (F) with the screw hole on the cylinder (C). Then, place the lower tube (F) over cylinder (C) and secure with the previously removed screw (D) using a screwdriver (not included).
10. Adjust gooseneck (H) to desired position.
11. Insert the plug (J) into a wall mains socket.
12. Use the HIGH (II)- OFF(O)- LOW (I) switch on lamp head to turn lamp on and off.

**TECHNICAL INFORMATION:**

Power supply: 220-240V ac; 50Hz
 LED output: 12W
 Class: II

THIS LAMP IS APPROVED FOR DOMESTIC INDOOR USE ONLY.

TIPS FOR OPTIMAL PERFORMANCE:

- Your LED lamp offers instant-ON, full power, so no need to let it “warm up”.
- Position the lamp head below eye level so light shines on your work space, not in your eyes.
- The LED Daylight Lamp is a TASK lamp, designed for reading, sewing and handiwork. It is not designed to light up an entire room or for ambient light.
- Bonus: LED Daylight Lamp is so close to sunlight that it makes a good grow light.

BULB LIFE EXPECTANCY:

- Integrated LED bulbs last up to 50,000 hours and do not require replacement.
- No user serviceable parts inside.

The LEDs are specially formulated to simulate the characteristics of natural sunlight. They are non-replaceable and should give up to 50,000 hours of use.

50,000 hours

365 days a year

Assume 4 hours use summer time 7pm – 11pm for 182.5 days every day = 730 hours

Assume 6 hours use winter time 5pm – 11pm for 182.5 days every day = 1095 hours

Total annual hours: 1825/50,000 = 27 years

This equipment has been tested and found to comply with the interference limits for a Class B digital device, pursuant to Part 15 of the FCC Rules and complies with LVD 2014/35/EU and EMC 2014/30/EU. If your lamp causes interference to radio communications, try to:

- Reorient or relocate the receiving antenna.
- Increase the separation between the lamp and receiver.
- Connect the equipment into an outlet on a circuit different from the receiver.

WARNINGS AND SAFETY INSTRUCTIONS:

- READ ALL INSTRUCTIONS BEFORE USE
- FOR DOMESTIC INDOOR USE ONLY.
- THE EXTERNAL FLEXIBLE CABLE OR CORD OF THIS LUMINAIRE CANNOT BE REPLACED. IF THE CORD IS DAMAGED, THE LUMINAIRE MUST BE DESTROYED SAFELY. NEVER USE THE UNIT IF ANY PART IS DAMAGED.
- BEFORE USE, CHECK THOROUGHLY FOR ANY DEFECTS AND DO NOT USE IF DEFECTS ARE FOUND. TAKE CARE NOT TO DROP THE APPLIANCE AS HEAVY IMPACTS MAY CAUSE INTERNAL DAMAGE.
- BEFORE CONNECTING THE APPLIANCE, CHECK IF THE VOLTAGE INDICATED ON THE BOTTOM OF THE APPLIANCE IS IN ACCORDANCE WITH THE MAINS VOLTAGE IN YOUR HOME.
- DO NOT PLACE ON OR NEAR HEAT SOURCES.
- USE ON A LEVEL, STABLE SURFACE.
- THERE ARE NO USER SERVICEABLE PARTS. IF A FAULT DEVELOPS, STOP USING THIS IMMEDIATELY AND DESTROY SAFELY. IF FAULT IS WITHIN THE GUARANTEE CONDITIONS THEN PLEASE RETURN TO THE RETAILER FOR REPLACEMENT OR REFUND.
- DO NOT LOOK DIRECTLY AT THE LIT LEDS.
- ROUTE THE POWER CABLE SO THAT IT WILL NOT GET WALKED ON OR PULLED TO AVOID TRIP HAZARDS.
- DO NOT ALLOW CHILDREN TO PLAY WITH THIS UNIT. IT IS NOT A TOY.

- THIS APPLIANCE CAN BE USED BY CHILDREN AGED FROM 8 YEARS AND ABOVE, AND PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES OR LACK OF EXPERIENCE AND KNOWLEDGE ONLY IF THEY HAVE BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE APPLIANCE IN A SAFE WAY AND UNDERSTAND THE HAZARDS INVOLVED. CHILDREN SHALL NOT PLAY WITH THE APPLIANCE. CLEANING AND USER MAINTENANCE SHALL NOT BE MADE BY CHILDREN WITHOUT SUPERVISION.
- CHILDREN OF LESS THAN 3 YEARS SHOULD BE KEPT AWAY UNLESS CONTINUOUSLY SUPERVISED.
- THE UNIT IS NOT INTENDED TO BE OPERATED BY MEANS OF AN EXTERNAL TIMER, DIMMER SWITCH OR SEPARATE REMOTE-CONTROL SYSTEM.
- DO NOT COVER THE ITEM IN ANY WAY WHEN IN USE AS THIS MAY CAUSE OVERHEATING.
- DO NOT USE THIS APPLIANCE FOR ANY OTHER USE THAN THE INTENDED USE IT IS DESIGNED FOR.
- TO PROTECT AGAINST ELECTRIC SHOCK, DO NOT IMMERSE POWER CABLE, PLUG OR APPLIANCE, IN WATER OR ANY OTHER LIQUID. DO NOT ALLOW THE UNIT TO GET WET.
- UNPLUG FROM OUTLET WHEN NOT IN USE AND BEFORE CLEANING.
- DO NOT OPERATE ANY APPLIANCE WITH A DAMAGED POWER CABLE OR PLUG OR AFTER THE APPLIANCE MALFUNCTIONS, OR HAS BEEN DAMAGED IN ANY MANNER. WE RECOMMEND THAT THE POWER CABLE IS NOT KINKED OR STORED IN A TWISTED MANNER, AND THAT YOU REGULARLY CHECK ITS CONDITION.

PLUG WIRING (UK & IRELAND)

This appliance is fitted with a BS 1363 13-amp plug.


If you have to replace the fuse, only those that are ASTA or BSI approved to BS1362 and with a rated current of 3-amps should be used. If there is a fuse cover fitted, this cover must be re-fitted after changing the fuse. If the fuse cover is lost or damaged the plug must not be used. Spare fuse holders and fuses are available from electrical outlets. If the socket outlets in your home or office are not suitable for this product's plug, the plug must be removed and disposed of safely. Attempts to insert the plug into the wrong socket is likely to cause electric hazard. A replacement plug should be wired according to the following instructions:

The cable

A mains electricity cable contains two or three inner wires. Each has a core of copper and an outer layer of flexible plastic. This product is double insulated; the wires in the plug are colour coded in the following way:

BLUE	NEUTRAL
BROWN	LIVE
GREEN & YELLOW	EARTH


The diagram below shows the key features of a correctly wired three-pin mains plug.



Note:

Double insulated appliances do not need the green & yellow Earth wire. They may only have the Brown and Blue wires.

ENERGY LABEL

**CARE AND CLEANING INSTRUCTIONS:**

- Always switch off and unplug before cleaning.
- Do NOT use polishes or cleaners.
- Wipe surfaces with a soft dry cloth.
- Allow to dry thoroughly before further use.
- Store the appliance in a dry, clean and stable place.

DISPOSAL:

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.

