



Assembly Instructions **Appleton Gazebo**

Code: 20771

V2




(W x D x H) 2.22m x 2.22m x 2.40m



ONLINE ASSEMBLY VIDEO AVAILABLE

Please scan the QR code or visit zestoutdoorlivingsupport.co.uk



PLEASE KEEP THESE INSTRUCTIONS



Every Zest product is unique because each piece of timber has its own distinctive, natural features.

Zest sources all of its timber from responsibly-managed forests and everything it designs and produces meets the highest standards of sustainability. Zest ensures that all timber and timber-related products are certified to Forestry Stewardship Council (FSC®).

This is vital not only for the health of the planet, but also shows Zest's commitment to the environment and to responsible sourcing. Timber is a natural material and, as such, will fit beautifully within any outdoor space. This also means that all Zest pieces are unique because every piece of timber has its own distinctive features.



Natural and Unique...

Changes in temperature and humidity will cause expansion and contraction so Zest products need time to adjust to where the owners live. A few splits or cracks are part of the maturing process and will not affect strength or durability. Knots embedded in the wood are natural and tell the story of the tree which made them. Customers may notice variations in colour but, once out in the garden and exposed to the sun, colour and shading will even out.

Most Zest products are pressure treated which protects the timber from rot and means customers will be able to enjoy the products in their garden for many years.

Fresh pressure treatment sometimes leads to a small amount of green-spotting on the surface of new timber as the natural salt leaves the wood. This will fade away over time and is in no way detrimental to quality or durability.


Splits and cracks occur naturally in the timber grain due to changing temperatures and humidity levels. They are not usually a cause for concern as they don't affect the strength or durability of the product. If however, a 2p coin can fit into the split or crack there may be an issue so it should be reported to the retailer in writing with photographic evidence.

The benefits of slow grown timber


“ Slow grown timber from Eastern Europe is ideal for timber garden furniture. It produces a stronger grain in the wood giving it more durability and is said to be as strong as some hard woods. ”




Normal splits are characteristics of timber.



Knots are characteristics of timber.



Sun Bleaching & Green Spotting are not causes for concern and they will fade over time when items are placed outdoors.



Should you find a large split or dead knot, please email a photo to your retailer for investigation.

FURNITURE | ARBOURS | GROW YOUR OWN | PLANTERS | TRELLIS | FENCING & MORE...

WWW.ZESTOUTDOORLIVING.CO.UK

Appleton Gazebo Assembly Instructions


Requires 2 Person assembly

Tools required: Corded / cordless drill, 3mm Drill bit, Pozi- drive bit / Screwdriver.

(*Crosshead) / Tape measure. (All screw holes to be pre-drilled)

Please take a few moments to check all pack contents listed



Appleton Gazebo Pack List			
Code	Item	Description	Quantity
21716	A	Post	4
21717	B	Back Panel	2
21718	C	Side Panel	2
21719	D	Bearer	2
21720	E1	Truss	2
21720	E2	Truss	2
21721	F	Upper Back Panel	1
21722	G	Bracing	8
21781	H	Square Edged Roof Board	4
21782	I	Roof Board	18
21725	J	Roof Batten	2
21783	K	Roof Capping	1
21727	L	Fascia	4
21728	M	Finial	2
21729	N	Hand Rails	2



This product is made from pressure-treated timber. It should not be painted or coated with any other treatment until at least 6 months after purchase


21785 - Appleton Gazebo Fixings List		
Item	Description	Quantity
1	120mm Screws	8
2	100mm Screws	12
3	80mm Screws	24
4	60mm Screws	8
5	45mm Screws	132

1





Place Back Panel (B) at a height of 90mm from base of Post (A), ensuring notch in Post (A) is facing outwards, fix in position using 2 x 100mm Screws.

2




Similarly fix second Post (A) to other end of Back Panel (B) using 2 x 100mm Screws.

3




Place remaining Back Panel (B) between Posts (A) as shown above and fix in position using w4 x 100m Screws (2 x Screws per Post).

4




Attach 1 x Side Panel (C) to Post/Panel assembly, at a height of 90mm from base of Post (A), using 2 x 80mm Screws.

5



Attach Post (A) (Notch facing outwards) to Side Panel (C), at a height of 90mm from base of Post (A), using 2 x 80mm screws.

6




Attach remaining Side Panel (C) to other side of Post/Panel assembly, at a height of 90mm from base of Post (A), using 2 x 80mm Screws.

7



Fix remaining Posts (A) (Notch facing outwards) to Side Panels (C), at a height of 90mm from base of Post (A), using 2 x 80mm Screws.


8



Position 1 x Bearer (D) into notches in Posts (A). Allow a 30mm overhang beyond back of rear Post (A) and to Rear Post fix using 2 x 60mm Screws. Fix Bearer (D) to front Post (A) using 2 x 60mm Screws.


Repeat procedure for remaining Bearer (D) on other side of Post/Panel assembly.

9





Place 1no. Truss (E1) directly above front Posts (A) and fix using 2 x 120mm Screws (1 x Screw per end)

10



Place remaining Truss (E1) flush with end of Bearers (D) and fix using 2 x 120mm Screws (1 x Screw per end).



11



Equally space 2 x Trusses (E2) between Trusses (E1) and fix to Bearers (D) using 4 x 120mm Screws. (2 x Screws per Truss, 1 x Screw per end).


Note: Trusses must be fixed onto Bearer (D) ensuring equal overhang at both ends.

12





Locate Upper Back Panel (F) between rear Posts (A) and fix using 4 x 100m screws (2 x Screws per post).

13




Ensure assembly is square and attach 8 x Bracings (G) (4 x Bracings per side) as shown, using 16 x 80mm Screws (2 x Screws per Bracing)

14



Place 1 x Square Edged Roof Board (H) (groove facing up) on to Trusses (E1 & E2). Allow a 10mm overlap at lower edge of trusses and fix to trusses using 4 x 45mm Screws

15



Interlock 9 x Roof Boards (I) and 1 x Square Edged Roof Board (H) and fix to Trusses E1 & E2 using 36 x 45mm Screws. (4 x Screws per board)

Repeat Stages 14 & 15 for remaining Square Edge Roof Board (H) and Roof Boards (I) on other side of assembly.

16



Position 1 x Roof Batten (J) beneath roof boards and fix using 4 x 45mm Screws.



Place remaining Roof Batten (J) beneath roof boards and fix using 4 x 45mm Screws.

17



Position Roof Capping (K) at apex of roof and fix using 8 x 45mm Screws (4 x Screws per side).

18



Ensuring Roof Battens (J) and all board ends are covered, attach 2 x Fascia's (L) (Ensure correct orientation of Fascia) to Roof Battens (J) using 6 x 45mm Screws. (3 x Screws per Fascia (L)).

19



Attach Finial (M) to Fascia's (L) using 2 x 45mm Screws.
Repeat Stages 18 & 19 for remaining Fascia's (L) and Finial (M) at rear of assembly.

20



Place Handrail (N) onto Side Panel (C) and fix using 5 x 45mm Screws.
Repeat procedure for remaining Handrail (N) on other Side Panel (C).

21



Your Appleton Gazebo is now complete.