



TECHNICAL DETAILS:

VOLTAGE:	6V d.c 4 x 1.5v AAA batteries (not included)
CURRENT:	300mA
WATTAGE:	4W

USER INSTRUCTIONS :

Battery installation:

- Rotate the bottom base cover counter clockwise and remove the base cover.
- Battery pack should come out but may need a gentle tap by hand to the side of the mill.
- Install 4x 1.5V 'AAA' batteries (not included) according to polarity which is indicated on the power pack.
- Refit the battery compartment back into the base, refit base and rotate clockwise until it clicks to secure.



USE:

Start using your gravity mill. For best results tilt it at an angle up to 60°. The built in sensor will then automatically dispense your salt or pepper.

TO REFILL:

- Remove the base with the power pack by turning it counter clockwise;
- Fill mill with peppercorns or sea salt crystals up to 80% of jar capacity. Do not over fill.
- Place the base with power pack back in place, ensure top and base cover are secure.

TO ADJUST GRIND LEVEL:

- Adjusting knob is located on top of the mill. Turn clockwise for fine grinding and counter-clockwise for a coarser grind.

WARNINGS / CAUTIONS:

- Never immerse your mill in water.
- Store your mill in a dry place.

CLEANING INSTRUCTIONS:

- Clean the outside of the mill with a soft damp cloth.
- Store in a cool dry location.

BATTERIES:

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.

